



## PLANA TRANSMITTER SWITCH

This transmitter is wireless, without battery, so without maintenance. Totally STAND-ALONE, it sends a radio signal thanks to power supplied when pressing keys on the switch.

MODULAR AND MOBILE: The transmitter switch can be placed at any place on a wall and be moved at will. Its adapted bottom allows to fix it on wall with screws or to stick it with double-sided adhesive tape.

It is especially convenient for electrical installations without embedding, for example: renovations, modification of home or office with moving walls.

Up to 30 transmitter switches can be combined with a receiver. Just press a switch key to manage any devices via receivers. Before any use, the switch must be associated to a receiver (see instruction manuals for synchronization).



## CODE 10020019 PLANA TRANSMITTER SWITCH 1 KEY WHITE CODE 10020001 PLANA TRANSMITTER SWITCH 2 KEYS WHITE

## **SPECIFICATIONS**

Transmission power	10mW max
Transmission frequency	868.3MHz
Dimensions	Base 80x80mm x height 15mm
Color	White
Operating temperature	From -25°C up to +65°C
Air relative humidity	From 0%up to 95%

