

## PLANA BLIND CONTROL TRANSMITTER SWITCH 2 KEYS WHITE

The blind control transmitter switch is wireless, without battery and almost flat. Totally STAND-ALONE, the switch sends a radio signal with power supplied by pressing ON and OFF keys from the switch, without any maintenance. Associated to a receiver and a luminosity detector, it allows to command afar various electrical equipment and especially the motorized shutters.

**MODULAR AND MOBILE:** The transmitter switch can be fixed at any place on a wall and be changed at will. Its adapted bottom allows to fix it on a wall with screws or to stick it with doublesided adhesive tape.

The blind control transmitter switch avoids tedious two-way switches wiring. It is possible to turn on an electrical device from a switch and to turn off the device from another one. Up to 30 transmitters per receiver, the possibilities are almost infinite without ripping walls and partitions. The applications are also infinite: schools, hotels, hospitals, historic buildings, offices, etc.

Delivered as complete ready to fit unit.



CODE 10020017 PLANA BLIND CONTROL TRANSMITTER SWITCH 2 KEYS WHITE

### SPECIFICATIONS

<i>Transmission power</i>	<i>10mW max</i>
<i>Transmission frequency</i>	<i>868.3MHz</i>
<i>Transmitter switch dimensions</i>	<i>Base 83x83mm x height 15mm</i>
<i>Color</i>	<i>White</i>
<i>Operating temperature</i>	<i>-25 to +65°C</i>
<i>Relative air humidity</i>	<i>From 0% to 95%</i>